



ПОЗИЦИЯ	ОБОЗНАЧЕНИЕ	К-ВО
1	KS.01	4
2	KS.04_1240	2
3	KS.03.1.13	6
4	KS.03.2.8.10	4
5	KS.03.2.8.15	2